

# Jabra Sport Coach Wireless

## How do I manually turn off/on voice guidance on my Jabra Sport Coach Wireless?

Voice guidance is turned on, as the default setting, on your Jabra Sport Coach Wireless.

To manually turn off/on voice guidance, follow these steps.

1. Turn off your Jabra Sport Coach Wireless by pressing and holding (3 seconds) the **Multi-function** button until the LED flashes red.
2. Simultaneously press and hold (3 seconds) the **Sports** button and the **Multi-function** button until the LED flashes red. A brief sound prompt will confirm the change.

