

Jabra GN8210 Digital audio enhancer

How do I install an amplifier to a Cisco IP telephone?

First check if the Cisco telephone has a RJ9 headset jack. If so, it is advantageous to use this jack for the ease of the call handling process. Follow these installation steps:

1. Install the connection cord, that came with the amplifier, from the amplifiers "telephone icon" jack to the Cisco phones' headset jack.
2. Install the quick disconnect cord in the amplifiers headset jack and the other appropriate end to the headsets' quick disconnect cord.
3. Install batteries (if applicable) into the amplifiers battery compartment or plug in the optional AC power supply.
4. With the amplifiers' lid opened, adjust the "battery saving feature" switch (if applicable) and the blue transmit volume knob.
5. Below the battery compartment; adjust the compatibility switch to "B" and close the lid.
6. Move the headset/handset (or phone/pc) toggle switch to headset/phone mode and make sure the mute toggle switch is not set on mute. As long as the Cisco phone is programmed for headset use; you are now ready to use the headset by pressing the Cisco phones' headset button.

If the Cisco telephone does NOT have a headset jack, follow these installation steps:

1. Unplug the Cisco telephone receiver handset cord from the base of the Cisco phone.
2. Install the connection cord, that came with the amplifier, from the amplifiers "telephone icon" jack to the Cisco phones' handset jack.
3. Install the Cisco telephones handset into the handset icon jack of the

- amplifier and then hang the handset receiver back on the phone.
4. Install the quick disconnect cord in the amplifiers headset jack and the other appropriate end to the headsets' quick disconnect cord.
 5. Install batteries (if applicable) into the amplifiers battery compartment or plug in the optional AC power supply.
 6. With the amplifiers' lid opened, adjust the "battery saving feature" switch (if applicable) and the blue transmit volume knob. Below the battery compartment; adjust the compatibility switch to "A" and close the lid.
 7. Move the headset/handset (or phone/pc) toggle switch to headset/phone mode and make sure the mute toggle switch is not set on mute. Lift the Cisco telephone handset receiver off the phone and you should have dialtone in the headset.

Applicable products

