

# Jabra Elite 45h - Black

## Wie verwende ich die Anruf- und Musiksteuerung auf meinem Jabra Elite 45h?

In der folgenden Tabelle findest du Informationen zu den grundlegenden Tastensteuerungen auf deinem Jabra Elite 45h Headset.

### Hinweis

Die Übersicht ist nur in englischer Sprache verfügbar. Versionen in anderen Sprachen findest du im übersetzten Benutzerhandbuch im Abschnitt Product documents (Produktunterlagen) auf der Produkt-Supportseite.

Play/pause music	Press the <b>Multi-function</b> button
Answer call	Press the <b>Multi-function</b> button
End call	Press the <b>Multi-function</b> button
Reject call	Double-press the <b>Multi-function</b> button
Adjust volume	Press the <b>Volume up</b> or <b>Volume down</b> button, when listening to music or on a call
Next track	Press and hold (1 sec) the <b>Volume up</b> button
Restart track or previous track	Press and hold (1 sec) the <b>Volume down</b> button to restart the current track Press and hold twice to play the previous track
Hear battery and connection status	Press the <b>Volume up</b> or <b>Volume down</b> button, when not listening to music or on a call
Activate Voice Assistant (Siri, Google Assistant)	Press the <b>Voice</b> button, when not on a call
Mute/un-mute microphone	Press the <b>Voice</b> button, when on a call.