

Jabra Pro 930 MS

Can I change the wireless range of my Jabra device after I have undocked it from the base?

Some devices need to be docked after the settings have been changed. Therefore, we recommend you first dock the headset and then change the settings.