


# Jabra Sport

## How do I reset my Jabra Sport?

When you reset your Jabra Sport, the list of devices that have been paired with it is cleared. Follow these steps to reset:

1. Turn on your Jabra Sport.
2. Simultaneously press and hold the **Volume +** button and the **Answer/end** button for approximately 6 seconds until the indicator light flashes red.



3. Your Jabra Sport is now reset, and it will shut down. When you turn it on again, it will go directly into pairing mode.

Note: When your Jabra Sport has been reset, you will need to re-pair it with your mobile phone. Remember to delete the previous pairing before you re-pair.