

Jabra Evolve 20 - USB-C/A, MS Stereo

Why did my Jabra device suddenly reboot?

Your Jabra device may suddenly reboot if it is managed by your IT department. There may be updated settings which require a reboot of your device. Note that a reboot will not happen if you are on a call.