


Jabra Engage 40 - USB-C UC Stereo

How do I mute/unmute the microphone on my Jabra Engage 40?

For the Jabra Engage 40 with inline controller, press the **Mute** button.



For the Jabra Engage 40 headset (without inline controller), use the mute controls from your computer.