

Jabra GN8050 TCA

What do I do when the On-Line Indicator does not light or flash?

- Make sure the Headset Stand/On-Line Indicator is fully inserted in the port on the back of the amplifier box.
- Make sure the batteries are properly installed.
- Replace the batteries with fresh batteries.
- Check that the headset is functioning.

The On-line Indicator will flash when a sound is detected in the headset, when you turn on the amplifier the first time, or when you mute the amplifier.

Note: The On-line Indicator is not a standard item with Jabra GN8000 or Jabra GN8050.

Applicable products



Jabra GN8050 TCA