


How do I mute/unmute the microphone on my Jabra Evolve2 50?

To mute/unmute the microphone on your Jabra Evolve2 50, press the **Play/pause** button when on a call.



Alternatively, move the microphone boom arm up to mute, or down to unmute.



The boom arm control for muting/unmuting the microphone is on by default. You can disable the setting using [Jabra Direct](#) on your computer.