


Jabra Speak2 75 - UC - Link 380a, Dark Grey

How do I manually reset the Jabra Speak2 75 to the default settings?

To reset the speakerphone to the factory settings, simultaneously press and hold (4 seconds) the **Answer call** button and the **End/reject call** button until "restore to factory default" is announced by the speakerphone.



Resetting the speakerphone clears all personalised settings and also clears the list of paired Bluetooth devices. After a factory reset, it is necessary to re-pair the Jabra speakerphone with your Bluetooth devices.