


Jabra Engage 55 - USB-C MS Stereo with Charging Stand

What do the buttons and LEDs on the Jabra Engage headset mean?


See the following diagrams for a description of the buttons and LEDs on the Jabra Engage headset.

The explanation is in English. For translated versions check the available languages of the user manual in the *Documents* section.

Convertible headset



Mono and stereo headset



Headset LED status

- Busylight
- ☀ Incoming call
- ☀ Headset powering on
- ☀ Headset powering off
- Headset fully charged
- ☀ Headset charging
- ☀ Firmware updating
- ☀ DECT pairing
- DECT connected

Applicable products



Jabra Engage 55 -
USB-A MS



Jabra Engage 55 -
USB-A UC Mono



Jabra Engage 55 -
USB-A MS Stereo



Jabra Engage 55 -
USB-A UC Mono with



Jabra Engage 55 -
USB-A MS Mono with



Jabra Engage 55 -
USB-A UC



Jabra Engage 55 -
USB-A MS Mono



Jabra Engage 55 -
USB-A MS Stereo



Jabra Engage 55 -
USB-A UC Stereo with



Jabra Engage 55 -
USB-C MS



Jabra Engage 55 -
USB-A UC Stereo



Jabra Engage 55 -
USB-C MS Mono



Jabra Engage 55 -
USB-C MS Stereo with



Jabra Engage 55 -
USB-C MS Mono with



Jabra Engage 55 -
USB-C MS Stereo



Jabra Engage 55 -
USB-C UC Convertible



Jabra Engage 55 -
USB-C UC Mono with



Jabra Engage 55 -
USB-C UC Stereo with



Jabra Engage 55 -
USB-C UC Mono



Jabra Engage 55 -
USB-C UC Stereo



Jabra Engage 65
Convertible



Jabra Engage 65
Stereo



Jabra Engage 65
Mono



Jabra Engage 75
Convertible



Jabra Engage 75
Stereo



Jabra Engage 75
Mono



Jabra Engage 75 SE -
Convertible



Jabra Engage 75 SE -
Mono



Jabra Engage 45 SE -
Convertible



Jabra Engage 45 SE -
Mono



Jabra Engage 45 SE -
Stereo



Jabra Engage 65 SE -
Convertible



Jabra Engage 65 SE -
Mono



Jabra Engage 65 SE -
Stereo

Jabra Engage 55 SE -
USB-A MS Mono



Jabra Engage 55 SE -
USB-A MS Stereo

Jabra Engage 65 SE -
Mono (Low Power)



Jabra Engage 55 SE -
USB-A MS Mono

Jabra Engage 55 SE -
USB-A MS



Jabra Engage 55 SE -
USB-A MS Stereo



Jabra Engage 55 SE -
USB-A UC Mono



Jabra Engage 55 SE -
USB-A UC



Jabra Engage 55 SE -
USB-A UC Mono



Jabra Engage 55 SE -
USB-A UC Stereo



Jabra Engage 55 SE -
USB-A UC Stereo



Jabra Engage 55 SE -
USB-C MS



Jabra Engage 55 SE -
USB-C MS Mono



Jabra Engage 55 SE -
USB-C MS Mono



Jabra Engage 55 SE -
USB-C MS Stereo



Jabra Engage 55 SE -
USB-C MS Stereo



Jabra Engage 55 SE -
USB-C UC Convertible



Jabra Engage 55 SE -
USB-C UC Mono



**Jabra Engage 55 SE -
USB-C UC Mono**



**Jabra Engage 55 SE -
USB-C UC Stereo**



**Jabra Engage 55 SE -
USB-C UC Stereo**