

Jabra Pro 9450 Mono Flex

How do I clean my Jabra product?

Keep your product clean by following these best practices for hygiene.

1. Apply normal dish soap and water to a cloth, making sure to wring out excess liquid so the cloth is not dripping wet. Use soap and water only – do not use strong cleaning agents.
2. Gently wipe the product, making sure there is not a layer of suds on the surface.
3. Let it rest for at least one minute.
4. Rinse the surface by wiping it with a slightly damp cloth using water only.
5. Let it dry.
6. When the product is not in use, keep it clean by avoiding contact with dirty surfaces. Dock it in the base, or store it in the protective case/pouch, if the product came with one of these options.