

Jabra Pro 9450 Mono Flex


How do I set my Jabra device as the default audio device on my macOS computer?

To manually set your Jabra device as the default audio device, follow these steps.

1. Click the **Apple** icon at the top left.



2. Select **System Preferences**.




3. Select **Sound**.



4. On the **Output** tab, select your Jabra device.

If you are using a Jabra device with a connected Link adapter, select the Link adapter.



5. On the **Input** tab, select your Jabra device.

If you are using a Jabra device with a connected Link adapter, select the Link adapter.

