

Jabra Solemate Mini


How do I manually turn off/on voice guidance on my Jabra Solemate Mini?

Voice guidance is turned on, as the default setting, on your Jabra Solemate Mini.

To manually turn off/on voice guidance, follow these steps.

Turn off voice guidance

1. Turn off your Jabra Solemate Mini.
2. Press and hold the **Volume -** button while you turn on your Jabra Solemate Mini.
3. Release the **Volume -** button when "sound prompts off" is announced. This indicates that voice guidance has been turned off.



Turn on voice guidance

1. Turn off your Jabra Solemate Mini.
2. Press and hold the **Volume +** button while you turn on your Jabra Solemate Mini.
3. Release the **Volume +** button when "sound prompts on" is announced. This indicates that voice guidance has been turned on.

