

Jabra Sport Wireless+

How do I know when my Jabra Sport/Sport+ is fully charged or needs to be charged?

On your Jabra Sport/Sport+, the battery LED flashes green when it is charging. When it is fully charged, the LED will change to solid green for approximately 60 seconds.

When the battery capacity goes below 10%, the battery LED will flash red, and you may hear a “low battery” announcement.