

Jabra PanaCast 50 Video Bar System ZR

How do I configure the Jabra PanaCast 50 Video Bar System?

Prerequisite

- Ensure that both the video bar and the touch controller are connected to the same local area network (LAN) and powered on.

When the Jabra PanaCast 50 Video Bar System has been installed and connected, it is ready to be configured.

The setup wizard, which is displayed on the touch controller and the video bar, will guide you through the following steps.

Configure using the touch controller

- Select the language
- Set the date and time
- Pair the touch controller with the video bar (if not pre-paired)
- Update the device firmware
- Select and start the video service provider* (if not pre-selected)

Configure using the video bar

If no touch controller is available, you can configure the PanaCast 50 Video Bar System using the video bar. This method requires the use of either a touch monitor or a wired keyboard and mouse.

- Select the language
- Set the date and time
- Update the device firmware
- Select and start the video service provider* (if not pre-selected)

After configuring the PanaCast 50 Video Bar System, the touch controller will display the video conferencing app of your service provider.

The next step is to configure the video bar settings. You can configure these settings using the touch controller or the Web Console.

*Microsoft Teams Room on Android or Zoom Room for Android