

Jabra Link 850

How do I adjust the microphone volume on my Jabra Link 850/860?

To adjust the microphone volume, turn the knob located on the underside of the Jabra Link 850/860. The default setting is 2, but you can select from 1 through 9.