

Jabra Evolve 65 TE - USB-A UC Mono

How do I know when my headset needs to be charged?

When the battery level reaches 5%, "Battery low" is automatically announced in the headset.

You can press the **Multi-function** button (when not on a call) to hear the battery status. "Battery medium" is announced when the remaining talk time is approximately 5 hours, and the remaining music time is approximately 7 hours.

Produits applicables



**Jabra Evolve 65 MS
Mono**



**Jabra Evolve 65 MS
Stereo**



**Jabra Evolve 65 UC
Stereo**



**Jabra Evolve 65 UC
Mono**



**Jabra Evolve 65+ MS
Stereo**



**Jabra Evolve 65+ MS
Mono**



**Jabra Evolve 65+ UC
Stereo**



**Jabra Evolve 65+ UC
Mono**



**Jabra Evolve 65 TE -
USB-A MS Mono**



**Jabra Evolve 65 TE -
USB-A MS Mono**



**Jabra Evolve 65 TE -
USB-A UC Mono**



**Jabra Evolve 65 TE -
USB-A MS Stereo**



**Jabra Evolve 65 TE -
USB-A UC Stereo**



**Jabra Evolve 65 TE -
USB-A UC Mono**



**Jabra Evolve 65 TE -
USB-A MS Stereo**



**Jabra Evolve 65 TE -
USB-A UC Stereo**