

Jabra UC Voice 550 MS Duo

Why did my Jabra device suddenly reboot?

Your Jabra device may suddenly reboot if it is managed by your IT department. There may be updated settings which require a reboot of your device. Note that a reboot will not happen if you are on a call.