


Jabra Solemate Mini

How do I reset my Jabra Solemate Mini?

When you reset your Jabra Solemate Mini, the list of devices that have been paired with it is cleared. Follow these steps to reset:

1. Press and hold (5 seconds) the **Answer/end** button and the **Volume +** button while you turn on your Jabra Solemate Mini.



2. Release the buttons when the pairing instructions are announced. Your Jabra Solemate Mini is now reset.

Note: When your Jabra Solemate Mini has been reset, you will need to re-pair it with your mobile phone. Remember to delete the previous pairing before you re-pair.