


## How do I reset my Jabra Rox Wireless?

When you reset your Jabra Rox Wireless, the list of devices that have been paired with it is cleared. Follow these steps to reset:

1. Press and hold (5 seconds) the **Multi-function** button and the **Volume +** button, until the Jabra Rox Wireless announces “disconnected” and then shuts down. Your Jabra Rox Wireless is now reset.



2. When you turn on your Jabra Rox Wireless again, it is ready to pair.

Note: When your Jabra Rox Wireless has been reset, you will need to re-pair it with your mobile phone. Remember to delete the previous pairing before you re-pair.