

Jabra Speak 710 MS


How do I turn off/on voice guidance on the speakerphone using Jabra Direct?

Prerequisites

- Device firmware - latest version
- [Jabra Direct - latest version](#)

To turn off/on voice guidance using Jabra Direct, follow these steps.

1. In Jabra Direct, select your device.
2. Click **Device**.
3. In **Device settings** > **Speakerphone** > **Voice guidance**, click the slider to turn the setting off/on.



4. Click **Apply**.

Note

Images and text are for guidance purposes only. Actual images and text

may vary depending on the connected device and updates to the software.

Applicable products



**Jabra Connect 4s -
USB-A**



Jabra Speak 710 MS



Jabra Speak 710 UC



Jabra Speak 750 - UC



**Jabra Speak 750 - MS
Teams**



**Jabra Speak2 40 UC,
Dark Grey**



**Jabra Speak2 40 MS
Teams, Dark Grey**



**Jabra Speak2 55 UC
Dark Grey**



**Jabra Speak2 55 MS
Teams, Dark Grey**



Jabra Speak 810 MS



Jabra Speak 810 UC



Jabra Speak 510



Jabra Speak 510 MS



Jabra Speak 510+



Jabra Speak 510+ MS