


# Jabra Speak 710 MS

## How do I mute/unmute the microphone on my Jabra speakerphone?

To mute/unmute your speakerphone, tap the **Mute** button.



### Note

Images are for guidance purposes only. The displayed image may differ slightly from your device, however the content is still relevant and accurate.

## Applicable products



Jabra Speak 810 UC



Jabra Speak 810 MS



Jabra Speak 710 MS



Jabra Speak 510 MS



Jabra Speak 750 - UC



Jabra Speak 710 UC



Jabra Speak 510+



Jabra Speak 510+ MS



Jabra Speak 510 for PC (SME)



Jabra Speak 510



Jabra Speak 750 - MS Teams



Jabra Connect 4s - USB-A