

Jabra Speak 710 UC

After connecting with my computer how do I ensure there is audio in the Jabra speakerphone?

After connecting, go to the audio settings for your computer and select the Jabra speakerphone as the playback device.

Applicable products



**Jabra Connect 4s -
USB-A**



Jabra Speak 410 MS



Jabra Speak 410



Jabra Speak 710 MS



Jabra Speak 710 UC



Jabra Speak 750 - UC



**Jabra Speak 750 - MS
Teams**



**Jabra Speak2 40 UC,
Dark Grey**



**Jabra Speak2 40 MS
Teams, Dark Grey**



**Jabra Speak2 55 UC
Dark Grey**



**Jabra Speak2 55 MS
Teams, Dark Grey**



**Jabra Speak2 75 - MS
Teams - Link 390a,**



**Jabra Speak2 75 UC -
Link 390c, Dark Grey**



**Jabra Speak2 75 - MS
Teams, Dark Grey**



**Jabra Speak2 75 - MS
Teams - Link 390c,**



**Jabra Speak2 75 - UC -
Link 390a, Dark Grey**



Jabra Speak 810 MS



Jabra Speak 810 UC



Jabra Speak 510



Jabra Speak 510 MS



Jabra Speak 510+



Jabra Speak 510+ MS



**Jabra Speak2 75 - UC,
Dark Grey**