

## Jabra Link 370 MS - Bluetooth Adapter

How do I adjust the wireless range settings on my Jabra Link Bluetooth adapter using Jabra Direct?

## **Prerequisites**

• Jabra Direct - latest version


To adjust the wireless range settings, follow these steps.

- 1. Make sure the Jabra Link Bluetooth adapter and the Jabra device are turned on and paired.
- 2. In Jabra Direct, select the Jabra Link Bluetooth adapter.
- 3. Click **Device**.
- 4. In **Device settings** > **Headset** > **Wireless range**, select the appropriate setting.

To support the maximum specified range between the Jabra Link Bluetooth adapter and the Jabra device, set the wireless range to **Normal**.

However, if there are many wireless devices present that could interfere with one another, then set the range to **Low** or **Very low**.





## 5. Click Apply.

## Note

Images and text are for guidance purposes only. Actual images and text may vary depending on the connected device and updates to the software.