


Jabra Engage 65 Mono


How do I mute/unmute the microphone on my Jabra Engage 65?

To mute/unmute the microphone on your Jabra Engage 65, press the Mute button on the headset or on the base.


Convertible headset



Mono and stereo headset



Base overview



Note

These images are in English. For translated versions check the available languages of the user manual in the **Product documents** section.