

Jabra Engage 75 Stereo

How do I manually reset my Jabra Engage 75 to the default settings?

When you reset your Jabra Engage 75, previously paired devices and settings will be cleared.


To reset using the controls on the base, use one of the following procedures.

Option 1

1. Dock the headset in the base.
2. Simultaneously press and hold (3 seconds) the **Answer call** button and the **End/reject call** button.

Option 2

1. Dock the headset in the base.
2. Press  for 2 seconds to open the **Advanced settings** menu.
3. Tap  to select **Base**, and then tap  to confirm your choice.
4. Tap  to navigate through the settings and select **Reset configuration**.
5. Tap  to select **Yes**, and then tap  to confirm your choice.



Note

After resetting, the headset and base will reboot and all settings will return to their default values.