

Jabra Elite Active 75t - Sienna

What is the maximum range between the earbuds?

The maximum range between the earbuds is 20cm/8in. If this range is exceeded, the earbuds may lose connection with each other. They will reconnect automatically if both earbuds are turned on and within range of each other.

If not, try placing both earbuds in the charging case. When you take them out, they will automatically turn on and reconnect.

Applicable products



**Jabra Elite 65t -
Copper Black**



**Jabra Elite 65t -
Titanium Black**



**Jabra Elite 65t - Gold
Beige**



**Jabra Elite 75t - Gold
Beige**



**Jabra Elite 75t -
Titanium Black**



Jabra Elite 75t - Black



**Jabra Elite Active 65t
- Titanium Black**



**Jabra Elite Active 65t
- Copper Blue**



**Jabra Elite Active 65t
- Amazon Edition**



**Jabra Elite Active 65t
- Copper Red**



Jabra Elite 85t - Black



**Jabra Elite 85t -
Copper Black**



**Jabra Elite 85t -
Titanium Black**



**Jabra Elite 85t - Gold
Beige**



**Jabra Elite Active 75t
- Copper Black**



**Jabra Elite Active 75t
- Navy**



Jabra Elite Active 75t
- Mint



Jabra Elite Active 75t
- Sienna



Jabra Elite Active 75t
- Dark Grey



Jabra Elite Active 75t
- Titanium Black



Jabra Elite Active 75t
Wireless Charging -



Jabra Elite Active 75t
Wireless Charging -



Jabra Elite 75t
Wireless Charging -



Jabra Elite 75t
Wireless Charging -



Jabra Elite 85t - Grey



Jabra Elite 85t - Grey
with 2 wireless



Jabra Evolve 65t MS



Jabra Evolve 65t UC