

Jabra Elite Active 75t - Dark Grey

Why did the audio pause when I removed one of my earbuds?

There are two factors that cause the audio to pause when you remove one of your earbuds.

- Auto-pause audio*

If you remove one of the earbuds while you are listening to audio, the audio will automatically pause. If you then replace the earbud in your ear within 60 seconds, the audio will resume automatically. If you replace the earbud in your ear after more than 60 seconds have passed, press the **Right** button to resume the audio.

- Near-Field Magnetic Induction (NFMI)

The earbuds use NFMI to connect with each other. When the earbuds are connected, the maximum range between them is 20cm/8in. If you remove one of your earbuds and the maximum range is exceeded, the NFMI connection is broken and the earbuds will then lose connection with each other.

- If the NFMI connection is broken and auto-pause audio is turned on, the smartphone will cease transmitting audio to the earbuds. The audio will pause regardless of which earbud you have removed.
- If the NFMI connection is broken and auto-pause audio is turned off, the left earbud will lose connection with the right earbud. If you have removed the left earbud, the audio will continue playing in the right earbud. However, if you have removed the right earbud, you will lose audio in the left earbud.

If both earbuds are turned on, bring them within range of each other to automatically reconnect them and restore the NFMI connection.

Note

*Auto-pause audio is on by default. To change this setting in Jabra Sound+ go to the Settings icon > Headset settings > Audio experience.

You can download Jabra Sound+ from [Google Play](#) on your Android device and from the [App Store](#) on your iOS device.

Applicable products



**Jabra Evolve2 Buds -
USB-A UC**



**Jabra Evolve2 Buds -
USB-A MS**



**Jabra Evolve2 Buds -
USB-C MS**



**Jabra Evolve2 Buds -
USB-C UC**



**Jabra Evolve2 Buds -
USB-A UC - Wireless**



**Jabra Evolve2 Buds -
USB-C UC - Wireless**



**Jabra Evolve2 Buds -
USB-C MS - Wireless**



**Jabra Evolve2 Buds -
USB-A MS - Wireless**



**Jabra Elite 75t - Gold
Beige**



**Jabra Elite 75t -
Titanium Black**



Jabra Elite 75t - Black



Jabra Elite 85t - Black



**Jabra Elite 85t -
Copper Black**



**Jabra Elite 85t -
Titanium Black**



**Jabra Elite 85t - Gold
Beige**



**Jabra Elite Active 75t
- Copper Black**



Jabra Elite Active 75t
- Navy



Jabra Elite Active 75t
- Mint



Jabra Elite Active 75t
- Sienna



Jabra Elite Active 75t
- Dark Grey



Jabra Elite Active 75t
- Titanium Black



Jabra Elite Active 75t
Wireless Charging -



Jabra Elite Active 75t
Wireless Charging -



Jabra Elite 75t
Wireless Charging -



Jabra Elite 75t
Wireless Charging -



Jabra Elite 85t - Grey



Jabra Elite 85t - Grey
with 2 wireless