

Jabra PanaCast 50 - Black

How do I adjust the image quality for the Jabra PanaCast 50?


Prerequisites

- [Jabra Direct - latest version](#)

Go to Jabra Direct > Jabra PanaCast 50 > Camera controller, where you can adjust the image for brightness, contrast, saturation, sharpness, and white balance.

You can also enable Vivid HDR and Automatic white balance. If Vivid HDR is enabled, you cannot adjust the contrast, saturation, and sharpness manually. If Automatic white balance is enabled, you cannot adjust the white balance manually.

When you adjust the settings, you can check your changes in real time. To do this, click **Camera preview** at the top of the screen. Note that the preview in Jabra Direct presents your video in a low resolution. If you want to see a full quality portrayal of your outgoing video stream, try using Windows Camera or another camera app.



Note

When using the camera controller, adjustments that are made to the image quality are temporary and not saved in Jabra Direct. The adjustments will apply until your computer is either disconnected from the Jabra PanaCast 50 or rebooted.

Setting changes made in Jabra Direct > Device > Settings are saved to the PanaCast 50, regardless whether your computer is disconnected from the Jabra PanaCast 50 or rebooted.