

# Jabra PanaCast 20

## How do I adjust the Pan, Tilt, Zoom on the Jabra PanaCast 20?


### Prerequisites

- [Jabra Direct - latest version](#)

You can adjust the Pan, Tilt, Zoom (PTZ) settings to align and center the camera view of the Jabra PanaCast 20.

To adjust the Pan, Tilt, Zoom, using the camera controller in Jabra Direct, follow these steps.

1. Go to Jabra Direct > Jabra PanaCast 20 > Camera controller.
2. Adjust the camera view using the Pan, Tilt, Zoom controls.
3. To check your changes in real time, click **Camera preview** at the top of the screen. The preview in Jabra Direct presents your video in a low resolution. If you want to see a full quality portrayal of your outgoing video stream, try using Windows Camera or another camera app.



## Note

The camera adjustments are temporary and will automatically reset to the default values when the connected computer is disconnected from the camera.

Images and text are for guidance purposes only. Actual images and text may vary depending on the connected device and updates to the software.