

## Jabra Elite 3 - Navy

### What can I do if one of my earbuds keeps flashing pink?

If one of your earbuds keeps flashing pink, you may have reset only one of the earbuds or the reset of both earbuds may have been interrupted.

To solve the issue, follow these steps.

1. Place both earbuds in the charging case with the lid open. Ensure your earbuds are sufficiently charged.
2. Press and hold (10 sec) the left and right buttons on the earbuds simultaneously until the earbud LEDs flash pink.
3. When the earbud LEDs stop flashing pink, the earbuds have been reset.

#### **Note**

The earbuds will need to be re-paired to your mobile device. Remember to delete/forget the previous pairing in the Bluetooth menu on your mobile device.

## Applicable products



**Jabra Elite 5 - Black**



**Jabra Elite 5 - Gold Beige**



**Jabra Elite 5 - Titanium Black**



**Jabra Elite 3 - Light Beige**



**Jabra Elite 3 Active**



**Jabra Elite 3 - Dark Grey**



**Jabra Elite 3 - Lilac**



**Jabra Connect 5t - Titanium Black**



**Jabra Elite 3 - Navy**