


# Jabra Elite 7 Active - Mint

## How do I charge my Jabra Elite 7 Pro/Active?

To charge your Jabra Elite 7 Pro/Active, place the earbuds in the charging case and close the lid. It takes approximately 2.5 hours to fully charge the earbuds and charging case.

When you open the lid, the LEDs on the earbuds will flash red, yellow, or green to indicate the battery status of the earbuds. The LED on the front of the charging case indicates the battery status of the charging case.




### Fast charge

When the earbuds are at low battery, 5 minutes of charge time will give up to 1.2 hours of battery. This fast charge option requires that the charging case has a minimum of 30% battery. You can check the current battery status of the earbuds and charging case in the Jabra Sound+ app.

### Charge the charging case using the USB cable

Plug the supplied USB-A to USB-C charging cable into the charging case and a USB-A power supply or certified wall charger. It takes approximately 2.5 hours to fully charge the earbuds and the charging case using the USB cable. Third party USB chargers may take longer to charge the charging case.



### Charge the charging case using a wireless charging pad

You can charge the charging case and earbuds using a charging pad. Place the charging case on the wireless charging pad and ensure that the charging case does not have a USB cable connected. The LED on the charging case will flash to indicate the charging case is placed correctly and is charging.

It takes up to 2.5 hours to fully charge the charging case and earbuds using a charging pad. When fully charged, the LED on the charging case will stay lit green. Third party wireless charging pads may take longer to charge the charging case.

### Note

Charging a device using a charging pad may result in the device becoming warm. The elevated temperature is within safe operating requirements and has no bearing on the lifespan or performance of the device.

