

# Jabra Elite 7 Active - Mint

## How do I change my preferred voice assistant in Jabra Sound+?

### Prerequisites

- [Jabra Sound+ - Android](#)
- [Jabra Sound+ - iOS](#)

By default, Jabra Sound+ and your Jabra device support the following voice assistants.

- iOS devices - Siri
- Android devices - Google Assistant

However, if you download and install the Amazon Alexa app to your iOS or Android smartphone, you can also use Amazon Alexa.

To change the preferred voice assistant for your Jabra device, follow these steps.

1. In Jabra Sound+, tap the Settings icon > Voice assistant.
2. Select your preferred voice assistant.