

# Jabra Elite 4 Active - Black

## Can I use just one of my Jabra earbuds?


Yes, you can use the right or the left earbud individually for playback of music or calls.

To activate mono earbud mode, place the unused earbud in the charging case. When you remove both earbuds from the charging case, the left and right earbuds will automatically relink and enter stereo mode.

### Note

For Android devices, stereo mixing must be enabled by selecting the SBC or Qualcomm® aptX™ audio codec in the Developer options on your smartphone.

View the following table for how to manage calls and music in mono earbud mode. Note that the explanations are in English. For other language versions, refer to the translated user manual in the Product documents section on the support page for your product.

Left button	Left earbud only
	Press the <b>Left</b> button when listening to music
	Press the <b>Left</b> button
	Double-press the <b>Left</b> button
	Press the <b>Left</b> button when on a call
	Double-press the <b>Left</b> button when not on a call
	Use the volume controls on the paired mobile device

**Right button    Right earbud only**

Play/pause music    Press the **Right** button when listening to music

Answer call    Press the **Right** button

End/Reject call    Double-press the **Right** button

Mute/unmute microphone    Press the **Right** button when on a call



Next track    Double-press the **Right** button when listening to music

Restart track or previous track    Triple-press the **Right** button when listening to music  
Repeat to skip to the previous track

Adjust volume    Use the volume controls on the paired mobile device