

Jabra Elite 4 Active - Mint

I lost the charging case for my true wireless earbuds - how do I purchase a replacement?

If you have lost the charging case for your true wireless earbuds, you can purchase a replacement charging case in the following two ways.

- On the Product support page for your product, expand the
 Accessories section to see the available accessories. For the charging case, click Add to cart.
- Go to the online accessory store, search for your product to see the available accessories. Click the charging case to add it to the cart.

Note

Before using the replacement charging case for the first time, please refer to the **Related Frequently Asked Questions** section below for information on how to connect the charging case with your current earbuds.