


Jabra Engage 55 - USB-A MS Stereo

How do I reset my Jabra Engage 55 to the default settings?

You can reset your Jabra Engage 55 manually or by using Jabra Direct.

To reset the headset manually, ensure that it is not connected to the Jabra Link 400. Then, simultaneously press and hold both the **Call** button and the **Volume up** button until the status LED flashes pink. After resetting, the headset will automatically enter pairing mode.



Note

After resetting you must re-pair your Engage 55 headset with the Link 400.