


Jabra Engage 50 II - (Engage 50 II Link) USB-C MS Stereo

How do I mute/unmute the microphone on my Jabra Engage 50 II?

For the Jabra Engage 50 II with Jabra Engage 50 II Link, press the **Mute/unmute** button.



For the Jabra Engage 50 II headset (without the Jabra Engage 50 II Link controller), use the mute controls from your computer.