

Jabra Link 400a USB-A, DECT, MS, NA

How do I use conference mode with the Jabra Link 400?

Conference mode lets you connect up to three additional headsets with one Jabra Link 400.

To connect a headset for conference mode, follow these steps.

1. Ensure the additional headset is turned off. Turn off the headset by pressing and holding (4 seconds) the **Call** button.
2. Press and hold (4 seconds) the **Call** button.
3. Press and hold (1 second) the button on the Jabra Link 400 DECT adapter to pair with the headset.
4. A voice prompt will play in the primary headset. Press the **Call** button on the primary headset to accept the additional headset to the conference call. The audio will now be shared between the headsets. By default, the additional headset will be muted.
5. Repeat these steps for each additional headset.

To end the call for all headsets, press the **Call** button on the primary headset.

Additional headsets can leave conference mode by pressing the **Call** button on the headset. The conference mode will continue for all other headsets.

You can configure conference mode settings using Jabra Direct.

Applicable products



Jabra Link 400c USB-C, DECT, MS, NA



Jabra Link 400c USB-C, DECT, UC, NA



Jabra Link 400a USB-A, DECT, MS, NA



Jabra Link 400a USB-A, DECT, UC, NA



Jabra Engage 55 - USB-C UC Stereo with MS



Jabra Engage 55 - USB-C UC Stereo



Jabra Engage 55 - USB-C UC Mono with MS



Jabra Engage 55 - USB-C MS Stereo with MS



Jabra Engage 55 - USB-A UC Mono



Jabra Engage 55 - USB-C UC Convertible



Jabra Engage 55 - USB-C MS Mono with MS



Jabra Engage 55 - USB-C MS Mono



Jabra Engage 55 - USB-C MS Stereo



Jabra Engage 55 - USB-A MS Stereo



Jabra Engage 55 - USB-A MS Stereo



Jabra Engage 55 - USB-C MS



Jabra Engage 55 -
USB-A UC Stereo with



Jabra Engage 55 -
USB-C UC Mono



Jabra Engage 55 -
USB-A UC Stereo



Jabra Engage 55 -
USB-A UC



Jabra Engage 55 -
USB-A MS Mono



Jabra Engage 55 -
USB-A MS Mono with



Jabra Engage 55 -
USB-A MS



Jabra Engage 55 -
USB-A UC Mono with



Jabra Engage 55 SE -
USB-A MS



Jabra Engage 55 SE -
USB-A MS Mono



Jabra Engage 55 SE -
USB-A MS Mono



Jabra Engage 55 SE -
USB-A MS Stereo



Jabra Engage 55 SE -
USB-A MS Stereo



Jabra Engage 55 SE -
USB-A UC Mono



Jabra Engage 55 SE -
USB-A UC Mono



Jabra Engage 55 SE -
USB-A UC Stereo



**Jabra Engage 55 SE -
USB-A UC**



**Jabra Engage 55 SE -
USB-A UC Stereo**



**Jabra Engage 55 SE -
USB-C MS Mono**



**Jabra Engage 55 SE -
USB-C MS Mono**



**Jabra Engage 55 SE -
USB-C MS Stereo**



**Jabra Engage 55 SE -
USB-C MS**



**Jabra Engage 55 SE -
USB-C UC Convertible**



**Jabra Engage 55 SE -
USB-C UC Mono**



**Jabra Engage 55 SE -
USB-C MS Stereo**



**Jabra Engage 55 SE -
USB-C UC Stereo**



**Jabra Engage 55 SE -
USB-C UC Mono**



**Jabra Engage 55 SE -
USB-C UC Stereo**

