


Jabra PanaCast 50 Room System MS

What is the difference between Intelligent Zoom and Virtual Director?

The Jabra PanaCast 50 features the following Automatic Zoom modes.

- **Intelligent Zoom** - dynamically frames all visible people within 4.5 meters (14 feet) of the camera.
- **Virtual Director** - utilizes advanced speaker tracking to focus the camera view on whomever is currently speaking.

By default, the Automatic zoom mode is set to Intelligent Zoom. You can configure the setting in Jabra Direct > PanaCast 50 > Settings > Camera > Automatic Zoom mode.



Note

After the Automatic Zoom mode has been set up, use the camera controller in Jabra Direct or Jabra Sound+, or use the remote control to access Intelligent Zoom or Virtual Director. Only one Automatic Zoom mode can be active at a time.

Applicable products



Jabra PanaCast 50
Room System ZR



Jabra PanaCast 50
Room System MS



Jabra PanaCast 50 -
Black



Jabra PanaCast 50 -
Grey



Jabra PanaCast 50
Room System 2 - IP



Jabra PanaCast 50
Room System 2 - USB