


Jabra Evolve2 65 Flex - USB-A MS Stereo

How do I mute/unmute the microphone on my Jabra Evolve2 65 Flex?

To mute/unmute the microphone on your Jabra Evolve2 65, press the **Voice** button when on a call.



Alternatively, move the microphone boom arm up to mute, or down to unmute.



The boom arm control for muting/unmuting the microphone is on by default. You can disable the setting using Jabra Sound+ ([Google Play](#) | [App Store](#)) on your smartphone or [Jabra Direct](#) on your computer.