

# Jabra Elite 8 Active - Black

## Why did the audio pause when I removed one of my earbuds?

### Prerequisites

- [Jabra Sound+ - Android](#)
- [Jabra Sound+ - iOS](#)

If you remove one of the earbuds while you are listening to audio, the audio will automatically pause. If you place the earbud in your ear again within 60 seconds, the audio will resume automatically. If you place the earbud in your ear again after more than 60 seconds have passed, press the **Right** button to resume the audio.

### Note

Auto-pause audio is on by default. To change this setting in Jabra Sound+, go to the Settings icon > Headset settings > Audio experience.

You can download Jabra Sound+ from [Google Play](#) on your Android device and from the [App Store](#) on your iOS device.

## Applicable products



**Jabra Elite 7 Active -  
Navy**



**Jabra Elite 7 Active -  
Black**



**Jabra Elite 7 Active -  
Mint**



**Jabra Elite 7 Pro -  
Gold Beige**



**Jabra Elite 7 Pro -  
Black**



**Jabra Elite 7 Pro -  
Titanium Black**



**Jabra Elite 7 Sport -  
Black**



**Jabra Elite 8 Active -  
Black**



**Jabra Elite 8 Active -  
Caramel**



**Jabra Elite 8 Active -  
Dark Grey**



**Jabra Elite 10 - Cocoa**



**Jabra Elite 10 -  
Titanium Black**



**Jabra Elite 10 - Gloss  
Black**



**Jabra Elite 10 - Matte  
Black**



**Jabra Elite 10 - Cream**



**Jabra Elite 8 Active -  
Navy**



**Jabra Elite 8 Active  
Gen 2 - Black**



**Jabra Elite 8 Active  
Gen 2 - Navy**



**Jabra Elite 8 Active  
Gen 2 - Coral**



**Jabra Elite 8 Active  
Gen 2 - Olive**



**Jabra Elite 10 Gen 2 -  
Titanium Black**



**Jabra Elite 10 Gen 2 -  
Gloss Black**



**Jabra Elite 10 Gen 2 -  
Cocoa**



**Jabra Elite 10 Gen 2 -  
Soft White**



**Jabra Elite 10 Gen 2 -  
Denim**