

Jabra Elite 10 Gen 2 - Titanium Black

Why do my earbuds beep when they are in the charging case?

The earbuds will beep when in the charging case if the charging case battery has been completely depleted. This is intended as a reminder to charge the charging case.

To stop the beeping, press the left and right earbud buttons simultaneously to turn the earbuds off.