


## Jabra Engage 45 SE - Stereo

**How do I connect my Jabra Engage to my Alcatel IP Touch 4029 or 4039 desk phone so I have remote call control using my headset?**

### **Prerequisite**

- Jabra Link 14201-36 Electronic Hook Switch (EHS) cable

### **Connect your headset**

1. For the 2-sided cable end:
  - a. Plug the (wide) RJ45 connector (red band) into the socket marked AUX on the Jabra base.
  - b. Plug the (small) RJ10 connector (blue band) into the socket marked with the phone icon  on the Jabra base.
2. For the 2-fold Y coupling end:
  - a. Plug the 3.5mm phone connector into the headset interface.
  - b. Plug the RJ12 phone connector plug into the socket marked with a bell on the phone.
  - c. Plug the phone cable for the phone directly into the additional connection socket of the Y-cable.

### **Configure your headset when connecting to a desk phone for the first time**

- For Jabra Engage 75/75 SE, follow the onscreen setup wizard on the base.
- For Jabra Engage 45 SE/65/65 SE, the initial setup is complete after connecting the cables.

## Additional setup information for your Jabra products

- EHS cable/adaptor type: MSH.
- Clear dial tone switch: set to position "A".
- We recommend setting the microphone volume to "7" out of 13.

## Phone settings with device software version 9.xx and later

Phone settings are no longer required. When the phone connector has been adapted correctly, a headset icon should appear in the phone display. If the headset icon does not appear, check the following settings: **Menu > Settings > Phone > Phone connector > Activate/select headset.**

## Phone settings with device software earlier than version 9.xx

Note that the "Force Headset" function must not be activated on the device as this will prevent you from accepting external calls.

**Menu > Settings > Phone > Phone connector > Force headset "OFF"**

**Menu > Settings > Phone > Socket > Activate headset.**

## Ringtone signal/phone settings

The ringtone signal on the headset is only transferred if one of the following ringtones has been selected: "Standard", "Classic", "Cold River", "Dooing-Dooing". Navigate to the menu:

**Menu > Settings > Ringtone > Internal/External.**

If you have set the correct ringtone and you still do not have a ringtone signal, check the following settings:

**Menu > Settings > Phone > Internal/External > additional options.**

The options "No tone", "Progressive", "Beeps" must be set to "OFF".

## **To connect/transfer calls using the headset**

1. Dial the phone number. “Transfer” appears on the phone display.
2. Press the associated function button next to the phone display.
3. End the conversation using the button marked “Headset”.