

Jabra Engage 75 SE - Convertible


What do the buttons and LEDs on the Jabra Engage headset mean?

See the following diagrams for a description of the buttons and LEDs on the Jabra Engage headset.


Note:

The following explanation is in English. For translated versions check the available languages of the user manual in the **Product documents** section.

Convertible headset



Mono and stereo headset



Headset LED status

- Busylight
- ☀ Incoming call
- ☀ Headset powering on
- ☀ Headset powering off
- Headset fully charged
- ☀ Headset charging
- ☀ Firmware updating
- ☀ DECT pairing
- DECT connected

Applicable products



Jabra Engage 65
Mono



Jabra Engage 55 -
USB-C UC Stereo with



Jabra Engage 75
Mono



Jabra Engage 75
Convertible



Jabra Engage 65
Stereo



Jabra Engage 55 -
USB-C UC Stereo



Jabra Engage 55 -
USB-C UC Mono with



Jabra Engage 75
Stereo



Jabra Engage 65
Convertible



Jabra Engage 55 -
USB-C MS Stereo with



Jabra Engage 55 -
USB-A UC Mono



Jabra Engage 55 -
USB-C UC Convertible



Jabra Engage 55 -
USB-C MS Mono with



Jabra Engage 55 -
USB-C MS Mono



Jabra Engage 55 -
USB-C MS Stereo



Jabra Engage 55 -
USB-A MS Stereo



**Jabra Engage 55 -
USB-A MS Stereo**



**Jabra Engage 55 -
USB-C MS**



**Jabra Engage 55 -
USB-A UC Stereo with**



**Jabra Engage 55 -
USB-C UC Mono**



**Jabra Engage 55 -
USB-A UC Stereo**



**Jabra Engage 55 -
USB-A UC**



**Jabra Engage 55 -
USB-A MS Mono**



**Jabra Engage 55 -
USB-A MS Mono with**



**Jabra Engage 55 -
USB-A MS**



**Jabra Engage 55 -
USB-A UC Mono with**



**Jabra Engage 75 SE -
Convertible**



**Jabra Engage 75 SE -
Stereo**



**Jabra Engage 75 SE -
Mono**



**Jabra Engage 45 SE -
Convertible**



**Jabra Engage 45 SE -
Mono**



**Jabra Engage 45 SE -
Stereo**



**Jabra Engage 65 SE -
Convertible**



**Jabra Engage 65 SE -
Stereo**

**Jabra Engage 55 SE -
USB-A MS**



**Jabra Engage 55 SE -
USB-A MS Mono**

**Jabra Engage 55 SE -
USB-A MS Mono**



**Jabra Engage 55 SE -
USB-A MS Stereo**

**Jabra Engage 65 SE -
Mono**



**Jabra Engage 55 SE -
USB-A MS Stereo**



**Jabra Engage 55 SE -
USB-A UC Mono**



**Jabra Engage 55 SE -
USB-A UC Mono**



**Jabra Engage 55 SE -
USB-A UC Stereo**



**Jabra Engage 55 SE -
USB-A UC**



**Jabra Engage 55 SE -
USB-A UC Stereo**



**Jabra Engage 55 SE -
USB-C MS Mono**



**Jabra Engage 55 SE -
USB-C MS Mono**



**Jabra Engage 55 SE -
USB-C MS Stereo**



**Jabra Engage 55 SE -
USB-C MS**



**Jabra Engage 55 SE -
USB-C UC Convertible**



**Jabra Engage 55 SE -
USB-C UC Mono**



**Jabra Engage 55 SE -
USB-C MS Stereo**



**Jabra Engage 55 SE -
USB-C UC Stereo**



**Jabra Engage 55 SE -
USB-C UC Mono**



**Jabra Engage 55 SE -
USB-C UC Stereo**