

Jabra Evolve2 40 SE USB-C/A, UC Mono

How do I manually turn off/on voice guidance on my Jabra Evolve2 40/Evolve2 30 headset?

Voice guidance is turned on by default on your Jabra Evolve2 40 or Evolve2 30 headset. To manually turn voice guidance off/on, simultaneously press and hold (5 seconds) the **Mute** button and the **Volume up** button on the right earcup until you hear an announcement in the headset.

Right earcup



Alternatively, you can turn off/on voice guidance using [Jabra Direct](#).