


Jabra GN9330e USB

How do I change the wireless range on the Jabra GN9330e and Jabra GN9330e USB?

To change the wireless range settings, follow these steps:

1. Place your Jabra headset on the base.



2. Press the **Phone** button on the GN 9330e, or the **PC** button on the GN9330e USB, for approximately 6 seconds until the online display (blue LED) on the headset starts to flash.
3. Press the **Phone** button to set the range of your headset. You can view the current setting in the charge display (yellow LED). The settings indicate the following ranges:
 - Normal = up to 120m
 - Low = up to 60m
 - Very Low = up to 25m

GN9330e:

Audiomode	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
NarrowBand \ Normal	<input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
NarrowBand \ Low	<input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
NarrowBand \ Very Low	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>

GN9330e USB:

With the Jabra GN9330e USB, you can also select the bandwidth range settings, from narrowband (300Hz -3400 Hz) to wideband (150Hz-6800Hz).

Audiomode \ PowerLevel	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
WideBand \ Normal	<input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
NarrowBand \ Normal	<input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
WideBand \ Low	<input checked="" type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
NarrowBand \ Low	<input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
WideBand \ Very Low	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>
NarrowBand \ Very Low	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>