

Jabra Pro 930 Mono

What does it mean when the Jabra Pro 930 battery indicator flashes blue and then stops flashing?

The battery indicator flashes blue when the unit enters sleep mode. This may happen after 8 hours of inactivity, for example if the USB host device is turned off, or if the USB cord is unplugged from the USB host device. See the User Manual for more information about sleep mode, and how to enable and disable it.