

Jabra Pro 930 Duo MS

How do I manually adjust the advanced settings on my Jabra Pro 900?

To adjust the advanced settings, follow these steps:

1. When not on a call, simultaneously press and hold both of the **Volume** buttons on the headset until you hear a beep.



2. Use the **Volume up** and **Volume down** buttons to toggle the setting. The current setting is announced in the headset. Use the **Answer/end call** button to accept your preferred setting.
3. Repeat step 2 to continue to adjust settings.
4. To exit the setup menu, simultaneously press and hold both of the **Volume** buttons on the headset until you hear a beep.

The advanced settings include:

- Mute reminder tone
- Base ringtone
- Base ringtone volume
- Intellitone
- Wireless range
- Remote call control