

## Jabra Stealth UC (MS)

### How do I adjust the wireless range settings on my Jabra Link Bluetooth adapter using Jabra Direct?

#### Prerequisites


- [Jabra Direct - latest version](#)

To adjust the wireless range settings, follow these steps.

1. Make sure the Jabra Link Bluetooth adapter and the Jabra device are turned on and paired.
2. In Jabra Direct, select the Jabra Link Bluetooth adapter.
3. Click **Device**.
4. In **Device settings > Headset > Wireless range**, select the appropriate setting.

To support the maximum specified range between the Jabra Link Bluetooth adapter and the Jabra device, set the wireless range to **Normal**.

However, if there are many wireless devices present that could interfere with one another, then set the range to **Low** or **Very low**.



5. Click **Apply**.

### Note

Images and text are for guidance purposes only. Actual images and text may vary depending on the connected device and updates to the software.